



05-08-05
 C3, 10, 12, & 13 were 27pf
 Added C15

04-07-2008

*For Dyno Vibrato Pedal & Dyno Suitcase Applications Omit Parts C14, R15, R16, R17, R18, & Q1.
 Then Place A Jumper Between Points A & B To Bypass The Transistor Circuit Wiring

Speakeasy Vintage Music

Dyno Preamp

T. Thompson
 S. Hayes

025-041010-003
 05/08/05

Page 1 of 3