

A, B, C, and RT Series Headphone Jack Kit

For use with any A, B, C, or RT series console connected to any Hammond™ tone cabinet or Leslie™ 31H, 21H, 22H, 122, etc.

**Contents**

- |                            |                     |
|----------------------------|---------------------|
| 1 - Headphone Kit Chassis  | 4 - 6 x ½" Screw    |
| 1 - Velcro™ mounting strip | 4 - P Clamp         |
| 1 - Instructions           | 4 - Wire nut (Gray) |

**Installation**

- Using the Velcro strip included, mount the headphone jack as shown.



Fig. 1 - B Series case



Fig. 2: C Series case (RT Similar)

- Route the attached cable into the interior of the cabinet by slipping it under the manuals and over the felt dust seal on the knee panel.
- Making sure that the cable is clear of any moving parts, secure it, and route it to the Preamp terminal panel where the audio connection is made (Red and Black wires, on terminals marked "G" and "G")
- Disconnect or cut the Red and Black wires on the "G-G" terminals.
- Using wire nuts or screw terminals (if so equipped) connect the Red and Black wires from the Headphone Kit to the terminals marked "G-G" on the preamp.
- Using wire nuts connect the organ's original Red and Black wires to the Green and White wires from the Headphone Kit.
- Connect the remaining wire, the one with the ring terminal installed, by securing it under any convenient chassis screw.

If the organ is connected to a 147, connect as follows:

Red - to one G terminal.	White - to Ground (Chassis).
Black - to Ground (Chassis).	Ring terminal lead to Ground (Chassis).
Green - to Pin 6 of the 147.	