



HOT ROD & OEM DRIVER KIT INSTRUCTIONS

Installation

1. Remove center & lower section back panels of the Leslie.
2. Unplug the green & black wire from the crossover.
3. Remove the upper driver. It is held in with 3 10/24 screws. Save the round spacer for future use.
4. Once the treble driver is removed, go back and check the plastic horn to see if there is a wad of cotton inside, if there is remove wad of cotton from the spinning section of the horn.
5. Remove the black & green wires from the old driver.
6. Remove the upper driver bearing plate assembly. At this point you should clean and degrease this item.
7. Remove the old Jensen driver from the gray mounting plate. Using the four screw holes that were holding the old driver, mount the new driver adaptor Mount using the screws provided.
8. Reinstall the old plate with the new mount and bearing assembly. Be sure to use the round spacer just as it came off the old driver.
9. Install the green/black wire harness on to the new treble driver. Connect the Green wire to the + terminal and the Black wire to the - terminal.
10. Screw the new treble driver onto the installed adaptor plate and plug the free end of the green/black wire harness into the crossover.
11. Install the tone cabinet backs, being sure to tighten all screws (If any screws are missing, replace them!).
12. Cover your ears and Have Fun!!

Speakeasy Vintage Music
3250 Schoolhouse Road
Dover, PA 17315
Ph: (717) 292-0814
Web: <http://www.speakeasyvintagemusic.com>