

Replacement 15" Leslie Woofer

Before installing your new woofer, it is necessary to install the special spacer rings onto the mounting face of the speaker basket. This is done in order to provide the clearance needed to keep the speaker cone from hitting the wood shelf to which it is mounted, at high volume levels.

To install the spacer, you will need an adhesive. We use silicone cement called "Goop"; you should have the same product or a similar one in your area.

Spread the adhesive on one section of the spacer and then place it onto the basket edge as shown. Repeat for the 3 remaining pieces.



Once all four pieces are in place, clamps, or a large weight such as a large heavy book should be placed on the top of the spacer to hold it in place while the glue dries. Be careful not to damage the cone of the speaker, and be patient and allow the glue to dry thoroughly.

Once dry, install the speaker as usual.